

## WESTERSTRAND TIME DISTRIBUTION

E1410.1 961015/CA

### **DESCRIPTION**

# - option RUNNING RESERVE art. no 122391-00

### General

The option *running reserve* is intended for situations where the master clock has to be working during power failure.

The master clock continues to send out minute impulses during the power failure, and the relay outputs are set to off position (0).

As a protection against low impulse voltage - during long lasting power failures - a low voltage alarm disconnects the battery when the voltage reaches a certain level.

#### **Technical data**

Battery pack: 24 V Ni-Cd, 600 mAh.

Capacity: Approx. 7 hours running reserve with max. load.

(1 Ampére load on the minute impulse output.)

Low voltage alarm: 20 V.

0506-480 00